

I. ARMING

When the door is closed, lock the door 3 turns with thumbturn or key. The alarm will be armed with a long warning tone. If the door is not closed or if the strike plate is not installed in a proper way (if there is not magnet on the strike plate), when you lock the door 3 times, “single”, “double” and “triple” tones will be heard and after 30 seconds, alarm will be armed with a long warning tone.

II. DISARMING

Unlock the lock with thumbturn or key. The alarm system will be disarmed with 4 short warning tones.

III. ADJUSTING SHOCK SENSITIVITY

When the door is opened (when the strike plate is not face to face with the lock) lock the door 3 turns. “Single”, “double” and “triple” tones will repeat one after the other.

STONE	SHOCK SENSITIVITY LEVEL
SINGLE	The most sensitive.
DOUBLE	The middle sensitivity level.
TRIPLE	The least sensitive.

After hearing the tone corresponding to desired level, unlock the door 1 turn. Desired level will be activated with a melodic warning tone.

IV. WARNING TONE SOUND LEVEL

After adjusting shock sensitivity, if you lock the door again with-in 5 seconds, “low volume” and “high volume” tones will repeat one after the other. After hearing desired sound level, unlock 1 turn. Desired level will be activated with a melodic warning tone. This adjustment doesn't change the alarm siren level, which is activated when the alarm is triggered.

V. MAINTENANCE

If you hear three short warning tones, everytime you arm or disarm the alarm system, batteries need to be changed. It is recommended to check the alarm siren once in six months as well. If the sound level is weak, change the batteries. It is powered by 2x AA size 1,5 V batteries. For changing the batteries, untighten the screw of battery holder (which has a battery sign on it) and take it out. Change the batteries, install it back and tighten the screw. Use only high quality alkaline or lithium batteries and don't use old and new batteries together.

The installation of the device is explained on the carton box.

KULLANMA KILAVUZU

I. ALARMIN DEVREYE ALINMASI

Kapı kapalıyken anahtar ya da tutamakla kilidi 3 tur kilitleyin.

Uzun uyarı tonuyla birlikte alarm devreye girecektir.

Eğer kapı kapalı değilse ya da kapı karşılığı doğru şekilde monte edilmediyse (kapı karşılığında bulunan mıknatıs yerinde değilse) kilit 3 tur kilitlendiğinde cihaz tek, çift ve üçlü uyarı tonu vermeye başlayacak ve 30 saniye sonra uzun uyarı tonuyla devreye girecektir.

II. ALARMIN DEVRE DIŞI BIRAKILMASI

Alarm devredeyken anahtar ya da tutamakla kilidi 1 tur açın. 4 kısa uyarı tonu ile birlikte alarm devre dışı kalacaktır.

III. DARBE HASSASİYET AYARI

Kapı kanadı açıkken (*kilit karşılığı, kilidin karşısında değilken*) kilidi 3 tur kilitleyin. Cihaz bir saniye arayla “tek”, “çift” ve “üçlü” uyarı sesi vermeye başlayacaktır.

UYARI SESİ	DARBE HASSASLIK SEVİYESİ
TEK	Darbelere karşı aşırı hassas.
ÇİFT	Darbelere karşı orta seviye hassasiyet.
ÜÇLÜ	Darbelere karşı düşük seviye hassasiyet.

Cihazın darbe hassaslığının hangi seviyede olmasını istiyorsanız, ilgili uyarı sesinden sonra kilidi 1 tur açınız. Melodik uyarı sesiyle birlikte ilgili ayar kaydedilmiş olacaktır.

IV. UYARI SESİ SEVİYESİ AYARI

Darbe hassasiyet ayarından sonra, 5 saniye içinde kilit tekrar kilitlenirse, bir saniye arayla “düşük” ve “yüksek” uyarı sesi duyulmaya başlanacaktır. İsteddiğiniz ses seviyesinden sonra kilidi 1 tur açınız. Melodik uyarı sesiyle birlikte ilgili ayar kaydedilmiş olacaktır.

Cihazın uyarı sesleri, alarm devreye girerken ya da devre dışı kalırken çıkan seslerdir. Bu seslerin düşük/yüksek ayarlanması, cihazın alarm esnasında çıkardığı sesin şiddetini değiştirmez.

V. BAKIM

Cihazın alarm sesi seviyesinin 6 ayda 1 defa kontrol edilmesi ve zayıflamış ise pillerin değiştirilmesi tavsiye edilir. Cihazın pillerinin en geç 2 yılda 1 defa değiştirilmesi önerilir.

Cihaz 2 adet AA tip 1,5 V Alkalin ya da lityum pille çalışır. Pil değiştirmek için, kapı açıkken, üzerinde pil sembolü olan pil kartuşunu sökün ve çıkartın. Pilleri değiştirdikten sonra kartuşu yerine yerleştirin ve vidalayın. Sadece yeni ve kaliteli pil kullanın. Eski pillerle yeni pilleri bir arada kullanmayın.

Cihazın montaj şekli, kutu üzerinde belirtilmiştir.